

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1000012 PWS NAME: CARROLLTON VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 1053067 STU NAME: CARROLLTON VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>RADIOLOGICAL Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH1000012      PWS NAME: CARROLLTON VILLAGE PWS

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: CARROLLTON, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	4 Sample(s) Monthly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1000112 PWS NAME: MALVERN VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 1053068 STU NAME: MALVERN VILLAGE OF**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>RADIOLOGICAL Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH1000112    PWS NAME: MALVERN VILLAGE PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: MALVERN, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	10 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	2 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1000412    PWS NAME: GREEN ACRES MOBILE ESTATES**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 1053072    STU NAME: GREEN ACRES MOBILE ESTATES**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>RADIOLOGICAL Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1000412      PWS NAME: GREEN ACRES MOBILE ESTATES**

**PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: GREEN ACRES MOBILE ESTAT DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1000512 PWS NAME: PRIDE VALLEY MHP**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 1053073 STU NAME: PRIDE VALLEY MHP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>RADIOLOGICAL Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1000512 PWS NAME: PRIDE VALLEY MHP**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: PRIDE VALLEY MHP DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>												
	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1000612 PWS NAME: ROCKWOOD PARK**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 1053074 STU NAME: ROCKWOOD PARK WATER SUPPLY**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>RADIOLOGICAL Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH1000612    PWS NAME: ROCKWOOD PARK

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: ROCKWOOD PARK DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
HAA5 & TTHM Sample Date(s):												
TCR Monthly Sample Date(s):												
	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sept	Oct	Nov	Dec
Total Chlorine Sample Date(s):												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1000812    PWS NAME: MOHAWK UTILITIES PUBLIC WATER SYSTEM**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 1053070    STU NAME: MOHAWK UTILITIES PWS PLANT 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>RADIOLOGICAL Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1000812      PWS NAME: MOHAWK UTILITIES PUBLIC WATER SYSTEM**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP002**  
**STU ID: 1053071    STU NAME: MOHAWK UTILITIES PWS PLANT 2**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>RADIOLOGICAL Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1000812      PWS NAME: MOHAWK UTILITIES PUBLIC WATER SYSTEM**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000**  
**FACILITY NAME: MOHAWK UTILITIES INC DISTRIBUTION**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	10 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	3 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>HAA5 &amp; TTHM Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1030112    PWS NAME: ATWOOD YACHT CLUB**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053077    STU NAME: ATWOOD YACHT CLUB**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1030212      PWS NAME: AUGUSTA ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 1053078      STU NAME: AUGUSTA ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1030212      PWS NAME: AUGUSTA ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: AUGUSTA ELEMENTARY SCH DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>HAA5 &amp; TTHM Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>Total Chlorine Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1030412    PWS NAME: CAMP ALDERSGATE PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1061614    STU NAME: CAMP ALDERSGATE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH1030912    PWS NAME: ABC COUNTRY CAMPING AND CABINS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053079    STU NAME: ABC COUNTRY CAMPING AND CABINS


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1031512    PWS NAME: FFA CAMP MUSKINGUM**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053081    STU NAME: FFA CAMP MUSKINGUM**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH1031512    PWS NAME: FFA CAMP MUSKINGUM  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 1060333    STU NAME: FFA CAMP MUSKINGUM STU 3  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP003</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP003 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1031712    PWS NAME: GOODS WOODS CAMPGROUND PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053082    STU NAME: GOODS WOODS MAIN CAMPGROUND STU 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1031712    PWS NAME: GOODS WOODS CAMPGROUND PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1060489    STU NAME: GOODS WOODS MAIN CAMPGROUND STU 2**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP002</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1032112    PWS NAME: COZY RIDGE CAMP-LOWER PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053084    STU NAME: COZY RIDGE CAMP-LOWER


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1032212    PWS NAME: COZY RIDGE CAMP-UPPER PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053085    STU NAME: COZY RIDGE CAMP-UPPER


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1032512    PWS NAME: D AND D DINER**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053087    STU NAME: D AND D DINER**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH1032612    PWS NAME: HEARTLAND HILL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 1053088    STU NAME: HEARTLAND HILL  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1032712    PWS NAME: DAVES DINER PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053089    STU NAME: DAVES DINER**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1033312    PWS NAME: SHERRODSVILLE ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 1053091    STU NAME: SHERRODSVILLE ELEMENTARY SCH**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1033312 PWS NAME: SHERRODSVILLE ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: SHERRODSVILLE ELEMENTARY DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1034112    PWS NAME: TWIN VALLEY CAMPGROUND**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053096    STU NAME: TWIN VALLEY CAMPGROUND**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH1034212    PWS NAME: WESTERN GRILL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 1053097    STU NAME: WESTERN GRILL  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1034512      PWS NAME: COLFOR MANUFACTURING**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 1053098      STU NAME: COLFOR MFG INC MALVERN**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1034512 PWS NAME: COLFOR MANUFACTURING**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: COLFOR MANUFACTURING DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1034612      PWS NAME: DELLROY ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 1053099      STU NAME: DELLROY ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1034612      PWS NAME: DELLROY ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: DELLROY ELEMENTARY SCH DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	<b>**</b> 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	<b>***</b> Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>HAA5 &amp; TTHM Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>Total Chlorine Sample Date(s):</i>				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1034812      PWS NAME: HARLEM SPRINGS ELEMENTARY**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 1053101      STU NAME: HARLEM SPRINGS ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1034812      PWS NAME: HARLEM SPRINGS ELEMENTARY**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: HARLEM SPRINGS ELEMENTAR DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 8/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>HAA5 &amp; TTHM Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>Total Chlorine Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1035012 PWS NAME: NEOSA SALVATION ARMY CAMP**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 1053103 STU NAME: NEOSA SALVATION ARMY CAMP**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1035212      PWS NAME: WILLIS ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 1053104      STU NAME: WILLIS ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1035212      PWS NAME: WILLIS ELEMENTARY SCHOOL**  
**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**  
**FACILITY NAME: WILLIS ELEMENTARY SCHOOL DISTRIBUTION**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>HAA5 &amp; TTHM Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>Total Chlorine Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1035612    PWS NAME: FALCON CAMP**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053106    STU NAME: FALCON CAMP**  
**Effective Date: 6/13/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
REVISED - NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
REVISED - NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 6/1/2008 and 8/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH1035712    PWS NAME: CAMP WAKONDA  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 1053107    STU NAME: CAMP WAKONDA  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1036212 PWS NAME: DELLROY DRIVE-IN RESTAURANT**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 1053109 STU NAME: DELLROY DRIVE-IN RESTAURANT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH1036412    PWS NAME: ELKHORN VALLEY CHRISTIAN CAMP**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053110    STU NAME: ELKHORN VALLEY CHRISTIAN SERVICE CAMP ST**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1036412    PWS NAME: ELKHORN VALLEY CHRISTIAN CAMP**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1060490    STU NAME: ELKHORN VALLEY CHRISTIAN SERVICE CAMP ST**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP002</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1036512    PWS NAME: GREAT TRAIL GSNEO CAMP-RANCH PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053111    STU NAME: GREAT TRAIL GSNEO CAMP RANCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1036612    PWS NAME: GREAT TRAIL GSNEO CAMP-MAIN PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053112    STU NAME: GREAT TRAIL GSNEO CAMP MAIN


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1036812    PWS NAME: GREAT TRAIL GOLF**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053113    STU NAME: GREAT TRAIL GOLF**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1037312 PWS NAME: MWCD DELLROY MARINA A-7**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 1053115 STU NAME: MWCD DELLROY MARINA A-7**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1037912    PWS NAME: MWCD LEESVILLE N FORK L-9

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053117    STU NAME: MWCD LEESVILLE NORTH FORK L-9


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1038012    PWS NAME: MWCD LEESVILLE N FORK L-5

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053118    STU NAME: MWCD LEESVILLE NORTH FORK L-5


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1038112 PWS NAME: MWCD LEESVILLE S FORK L-7**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 1053119 STU NAME: MWCD LEESVILLE SOUTH FORK L-7**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1038212 PWS NAME: MWCD LEESVILLE S FORK L-1**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 1053120 STU NAME: MWCD LEESVILLE SOUTH FORK L-1**


**Effective Date: 5/16/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>REVISED - TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1038311      PWS NAME: MWCD-ATWOOD RESORT**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Surface Water      Sample Monitoring Point: EP001**

**STU ID: 1053121      STU NAME: MWCD ATWOOD RESORT**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) Monthly
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>TOTAL ORGANIC CARBON (TOC)</b>		1 Paired Sample Set Monthly *
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

Paired Sample Set: \* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>												
<i>INORGANIC Sample Date(s):</i>												
<i>NITRATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>TOC Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>VOC Sample Date(s):</i>												
<i>SOC Group 1 Sample Date(s):</i>												





**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1038612    PWS NAME: DEBS FAMILY RESTAURANT PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053124    STU NAME: DEBS FAMILY RESTAURANT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1039112      PWS NAME: SUMMITVILLE TILES, INC.**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 1053128      STU NAME: SUMMITVILLE TILES INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH1039112      PWS NAME: SUMMITVILLE TILES, INC.

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: SUMMITVILLE TILES, INC. DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>HAA5 &amp; TTHM Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>Total Chlorine Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1039212    PWS NAME: SEVEN RANGES BOY SCOUT C**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053129    STU NAME: SEVEN RANGES BOY SCOUT CAMP**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1039312    PWS NAME: HARRISON HILLS CAMP 2 & 3 PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053130    STU NAME: HARRISON HILLS CAMP 2 & 3 STU 1


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1039312 PWS NAME: HARRISON HILLS CAMP 2 & 3 PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 1060491 STU NAME: HARRISON HILLS CAMP 2 & 3 STU 2**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP002</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1039412    PWS NAME: HARRISON HILLS CAMP 4 PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053131    STU NAME: HARRISON HILLS CAMP 4**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1039512    PWS NAME: HARRISON HILLS CAMP 5 PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053132    STU NAME: HARRISON HILLS CAMP 5**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1039612    PWS NAME: HARRISON HILLS CAMP 6 PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053133    STU NAME: HARRISON HILLS CAMP 6**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1039712    PWS NAME: CARROLLTON ASSEMBLY OF GOD**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053134    STU NAME: CARROLLTON ASSEMBLY OF GOD INC**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1040012    PWS NAME: SHERRODSVILLE LIONS CLUB**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053136    STU NAME: SHERRODSVILLE LIONS CLUB**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1040812    PWS NAME: CAMP GIDEON EVAN FRIENDS CHURCH CAMPGROU**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053140    STU NAME: CAMP GIDEON EVAN FRIENDS CH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1040912    PWS NAME: KILGORE UNITED METHODIST**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053141    STU NAME: KILGORE UNITED METHODIST CH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH1041012    PWS NAME: HARSH MEMORIAL UNITED METHODIST CHURCH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053142    STU NAME: HARSH MEMORIAL UN METHODIST CH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1041112 PWS NAME: ST. MARY OF MORGES CHURCH**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 1053143 STU NAME: SAINT MARY OF MORGES CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1041412    PWS NAME: MT. PLEASANT UNITED METHODIST CHURCH PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053146    STU NAME: MT PLEASANT UNITED METHODIST C


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1041512    PWS NAME: CHURCH OF THE NAZARENE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053147    STU NAME: CHURCH OF THE NAZARENE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1041712    PWS NAME: CALVARY METHODIST CHURCH**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053149    STU NAME: CALVARY METHODIST CHURCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1041812    PWS NAME: CHRIST COMMUNITY CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053150    STU NAME: CHRIST COMMUNITY CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1041912 PWS NAME: ELKHORN VALLEY RETREAT CENTER**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 1053151 STU NAME: ELKHORN VALLEY RETREAT CENTER**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH1042012    PWS NAME: CAMP GIDEON RETREAT CENTER

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 1053152    STU NAME: CAMP GIDEON RETREAT CENTER


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1042112    PWS NAME: CATHYS KITCHEN PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1053153    STU NAME: CATHYS KITCHEN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1042212      PWS NAME: GLADE RUN MENNONITE CHURCH**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 1053154      STU NAME: GLADE RUN MENNONITE CHURCH**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 5/31/2008

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>INORGANIC Sample Date(s):</i>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1042212 PWS NAME: GLADE RUN MENNONITE CHURCH**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: GLADE RUN MENNONITE CH DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 5/31/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

*Lead & Copper Sample Date(s):*

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1042312    PWS NAME: PRIDE VALLEY CAMPGROUND**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053155    STU NAME: PRIDE VALLEY CAMPGROUND**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH1042412    PWS NAME: J & BS STEAKHOUSE PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 1053156    STU NAME: J & BS STEAKHOUSE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH1042712    PWS NAME: UNCLE MIKES CAFE PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 1061889    STU NAME: UNCLE MIKES CAFE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1042812 PWS NAME: KINGS PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 1062239 STU NAME: KINGS**

**Effective Date: 7/18/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>REVISED - INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>REVISED - NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>REVISED - NITRITE</b>	NITRITE (AS N) - 1041	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>REVISED - VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>REVISED - SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>INORGANIC Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>NITRITE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1042812 PWS NAME: KINGS PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: KINGS DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

---

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH1043212    PWS NAME: CARROLL HILLS INDUSTRIES PWS**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 1062160    STU NAME: CARROLL HILLS INDUSTRIES**

**Effective Date: 6/13/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>REVISED - INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>REVISED - NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>REVISED - NITRITE</b>	NITRITE (AS N) - 1041	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>REVISED - VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>REVISED - SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>INORGANIC Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>NITRITE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH1043212 PWS NAME: CARROLL HILLS INDUSTRIES PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: CARROLL HILLS INDUSTRIES DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---